

Please use this manual change for the manuals as listed in below.

1. Applicable User's Manuals

IM No.	Edition	Products	Section	Page
IM 01C27B01-01EN	15	EJX110B, EJX310B, EJX430B Differential Pressure and Pressure	8.4.2 9.5.3	8-19 9-11
IM 01C27F01-01EN	12	EJX510B, EJX530B Absolute and Gauge Pressure Transmitter	8.4.2 9.5.3	8-18 9-14
IM 01C27C01-01EN	12	EJX210B Flange Mounted Differential Pressure Transmitter	8.4.2 9.5.3	8-19 9-12
IM 01C27H01-01EN	12	EJX118B, EJX438B Diaphragm Sealed Differential Pressure and Gauge Pressure	7.4.2 8.5.3	7-19 8-12

2. Contents of Change

Addition of "NOTE".

Before Change	After Change
NONE	 NOTE A critical low battery alarm may be happened even if battery power of device is remaining. When unexpected alarm is happened, please restart the device by power off/on or Field Wireless Device Restart Tool. Field Wireless Device Restart Tool is available in "Downloads" tab at following website: https://www.yokogawa.com/solutions/products-platforms/field-instruments/ .