

Drawings


EJX118A Diaphragm Sealed Differential Pressure Transmitter (Transmitter body section)

DPharp **EJX**®

SD 01C25H01-01E


[Style: S2]

Unit: mm (approx. inch)



*1: When electrical connection code 7 or C is selected, a blind plug is protruded up to 8 mm from the conduit connection.

- Terminal Configuration



- Terminal Wiring

| | | | |
|--------|---|---|--|
| SUPPLY | + | ① | Power supply and output terminals |
| | - | ② | External indicator (ammeter) terminals*1*2 |
| CHECK | + | ③ | or |
| or | - | ② | Status contact output terminals*2 |
| ALARM | + | ③ | (when /AL is specified) |
| | - | ② | |
| | | | Ground terminal |

*1: When using an external indicator or check meter, the internal resistance must be 10 Ω or less. A check meter or indicator cannot be connected when /AL option is specified.

*2: Not available for FOUNDATION Fieldbus and PROFIBUS PA communication types.